



White circles are where have to solder the female headers.

The board is sold just like on the above picture.

Male and female headers are included but not soldered. Two 100nF capacitors are included. If one will use Crystek, DIP14 or DIP8 oscillators, these capacitors must be soldered on C4 and C6, if one will use NDK oscillators, the two capacitors must be soldered on C25 and C26.

Note: Don't forget to cut the external clock jumper on I2SoverUSB board.

How to power the I2SoverUSB and oscillator boards:

1. Apply +5.0 to 5.2V (150mA) to oscillator board on Power supply pins

How to power the I2SoverUSB, AK4396 and oscillator boards:

1. Apply +5.0 to 5.2V (250mA) on the AK4396 board